



## CMS 4000 Monitoring Station

CMS 4000 is a self contained monitoring station that provides call handling for Tunstall personal emergency response units.

Alarm calls may be received, one at a time and either presented to the CMS operator, transferred to a wireless telephone or logged and cleared down automatically depending on rules configured within CMS 4000.

The CMS operator or a technician has the capability to remotely program a Telecom 4000 or Telecom 400, eliminating the need for onsite service calls.



## Features

- Easy to install on a normal telephone line reducing the cost of installation
- LCD display for call and status information
- 2 way speech using integral handsfree loudspeaker and microphone or external telephone
- Fully configurable for operator calls handling or background call logging depending on call type
- Attended / Unattended mode, allowing configurable call forwarding to a designated telephone
- Optional Log printer for audit trail of calls events
- Optional Database for storage and display of client records
- 8 hour battery backup

# Technical Details

- Part Number:** 36104/700
- Fixing Details:** Tabletop or wall mounting
- Battery:** > Integral, re-chargeable battery, replaceable  
> 8 hour battery backup with automatic status reporting
- Connections:** Standard telephone jack connection (RJ11 linecord included). AC power via an AC adapter (included). RS232 data via a Tunstall interface module and 9 way D cable (included)
- Dimensions:** W 6.7" x H 2.2" x D 9.2" (170mm x 55mm x 233mm)
- Operating Temperature Range:** 14° F to 131° F (-10° C to +55° C)
- Standards:** FCC CFR47 part 15, Canadian RSS210
- Product Compatibility:** Premier, Portal, Telecom 400, Telecom 4000, Caresse, Caresse+
- Optional Parts:** Tunstall CMS 4000 database software application version 5.0 part number 75089044

# Contact Details

Tunstall Group Limited  
10N. Martingale Road Suite 400  
PMB259  
Schaumburg  
Illinois 60173-2411  
USA  
Tel: 1-800-892-2205  
Fax: +44 1977 660562  
Email: [sales@tunstallamerica.com](mailto:sales@tunstallamerica.com)

Tunstall Canada  
7540 Bath Road  
Mississauga  
Ontario L4T 1L2  
CANADA  
Tel: 905-677-1144  
Fax: 905-677-1121  
Email: [sales@tunstallamerica.com](mailto:sales@tunstallamerica.com)



[www.tunstallamerica.com](http://www.tunstallamerica.com)

Our policy of continual development means that product specification and appearance may change without notice. © 2008 Tunstall Group Ltd. © TUNSTALL is a registered trade mark.