



Flood Detector

The flood detector is a neat, unobtrusive radio sensor that provides an early warning of potential flood situations. The unit can be placed on the floor under a sink or in a bathroom, next to the toilet or near the bath.

The flood detector has three sensors. When two of the sensors make contact with water it provides two types of alarm - the first is a local audible alarm and the second sends a signal to a Tunstall Telecom or Caresse unit. The unit automatically raises a call to the monitoring centre where the operator can identify which type of detector has initiated the call, allowing the most appropriate and immediate action to be taken.



Features

- Wireless connection to Telecom 400/4000 and Caresse/Caresse+
- Generates an audible warning of flood as well as triggering a call on the host unit.
- Generates an audible warning of low battery

Technical Details

- Part Number:** 64604/09
- Radio Frequency:** 312.000 MHz
- Battery:**
- > One 9 volt PP3 style battery (user replaceable). Typical life 2 years.
 - > One Hardwired 3 volt cell for the transmitter (not user replaceable) Typical life 3.5 years
 - > Automatic low battery transmission to the host unit
- Dimensions:** 3.6" diameter x 1.2"H (90 x 31mm)
- Weight:** 0.31lbs (0.142Kg)
- Operating Temperature Range:** 14° F to 131° F (-10° C to +55° C)
- Radio Range:** 213 ft (65 m) in free space
- Supervision:** Auto Low Battery
- Standards:** FCC CFR47 part 15, Canadian RSS210
- Product Compatibility:** Telecom 400, Telecom 4000, Caresse, Caresse+

Contact Details

Tunstall Group Limited
10N. Martingale Road Suite 400
PMB259
Schaumburg
Illinois 60173-2411
USA
Tel: 1-800-892-2205
Fax: +44 1977 660562
Email: sales@tunstallamerica.com

Tunstall Canada
7540 Bath Road
Mississauga
Ontario L4T 1L2
CANADA
Tel: 905-677-1144
Fax: 905-677-1121
Email: sales@tunstallamerica.com



www.tunstallamerica.com

Our policy of continual development means that product specification and appearance may change without notice. © 2008 Tunstall Group Ltd. ® TUNSTALL is a registered trade mark.