



PIR Movement Detector

The PIR is a wireless movement detector that detects activity within a dwelling. The PIR works in conjunction with the Telecom 400/4000 and Caresse/Caresse+ units to provide inactivity monitoring and with Telecom 4000/Caresse+ to provide intruder monitoring.

The Optex EX-35R has been used by Tunstall successfully for many years and has demonstrated reliability and quality.



Features

- Optex EX-35R with integrated Tunstall 312MHz radio transmitter
- Optex detection performance - typical coverage of 35 feet by 35 feet
- Screw adjustment to give pet alley performance
- Lens reversal to give long range performance (55 feet by 5.5 feet).
- Host battery voltage monitoring and automatic battery low detection
- 4 hour supervision transmissions
- Automatic low battery reporting
- Switchable LED for walk test or normal operation (Switch LED off after installation to increase battery life)

Technical Details

Part Number:	64604/03
Fixing details:	Back box with knockouts for screw mounting to wall (screws for wooden surface mounting provided). Mounting height normally 4 to 8 ft. Pet alley 2 to 4 ft.
Radio Frequency:	312.000 MHz
Battery:	> 9 volt PP3 size battery (Alkaline battery supplied) > Typical life 18 months for 20 activations per day (Alkaline battery), life 36 months for 20 activations per day (Lithium battery). These include supervision transmissions. > Battery is field replaceable, the unit has to be unscrewed / partially dismantled.
Dimensions:	W 2.76" x H 4.49" x D 2.99" (70mm x 80mm x 23mm)
Weight:	0.31lbs (142g)
Operating Temperature Range:	14° F to 131° F (-10° C to +55° C)
Radio Range:	300 ft to 450ft (91 m to 137 m) in free space
Supervision:	Full
Standards:	FCC CFR47 part 15, Canadian RSS210
Product Compatibility:	Telecom 400, Telecom 4000, Caresse, Caresse+

Contact Details

Tunstall Group Limited
10N. Martingale Road Suite 400
PMB259
Schaumburg
Illinois 60173-2411
USA
Tel: 1-800-892-2205
Fax: +44 1977 660562
Email: sales@tunstallamerica.com

Tunstall Canada
7540 Bath Road
Mississauga
Ontario L4T 1L2
CANADA

Tel: 905-677-1144
Fax: 905-677-1121
Email: sales@tunstallamerica.com



www.tunstallamerica.com

Our policy of continual development means that product specification and appearance may change without notice. © 2008 Tunstall Group Ltd. ® TUNSTALL is a registered trade mark.