



Telecom Common Area Unit

The Telecom Common Area Unit provides pendant coverage for residents within common areas, for example lounge or dining rooms.

It will respond to any resident's Amie, Gem or Fall detector pendant and route an emergency call to care providers. The Common Area Unit can also be used to provide staff safety.



Features

- Easy to install on a normal telephone line reducing the cost of installation
- Configuration Options – Emergency calls can be directed to, pocket pagers, wireless telephones, a telephone switch or a professional monitoring center
- Call escalation – can call up to 6 different telephone numbers
- 2 way handsfree speech during emergency call
- Identification of unit ID and pendant ID to the call recipient.
- When a Telecom 4000 (36004/414) is used, a voice tag can be recorded and played back to explicitly identify the location of the unit to the recipient

Technical Details

Part Number:	36004/013 (Telecom 400 with CAU configuration) or 36004/414 (Telecom 4000 with CAU configuration)
Fixing Details:	Tabletop or wall mounting
Battery:	> Integral, re-chargeable battery, replaceable > 8 hour battery backup with automatic status reporting
Connections:	Standard telephone jack connection (RJ11 linecord included). AC power via an AC adaptor (included). Wiring terminals for interface to dome light (not included).
Dimensions:	W 6.7" x H 2.2" x D 9.2" (170mm x 55mm x 233mm)
Radio Range:	213 ft (65 m) in free space
Standards:	FCC CFR47 part 15, Canadian RSS210, ETL/UL1635, ETL/UL1637
Product Compatibility:	Premier, Portal, Telecom 400, Telecom 4000, Caresse, Caresse+
Optional Parts:	RJ31x line cord part number XD3605044A

Contact Details

Tunstall Group Limited
10N. Martingale Road Suite 400
PMB259
Schaumburg
Illinois 60173-2411
USA
Tel: 1-800-892-2205
Fax: +44 1977 660562
Email: sales@tunstallamerica.com

Tunstall Canada
7540 Bath Road
Mississauga
Ontario L4T 1L2
CANADA
Tel: 905-677-1144
Fax: 905-677-1121
Email: sales@tunstallamerica.com



www.tunstallamerica.com

Our policy of continual development means that product specification and appearance may change without notice. © 2008 Tunstall Group Ltd. ® TUNSTALL is a registered trade mark.